

EXTERNAL MICROPHONE

BASIC OPERATION AND SETTINGS



Using External Microphone(s)

- Watch *Using External Mics* video (stop after 7min-- video repeats info in *Getting Started*)
- Using External Mics (timestamp at 1:00)
<https://youtu.be/Nt-537vollO?t=1m1s>

To use the H5 with a Shotgun Microphone, follow these basic steps:

1. Connect the XLR cable to input 1 or 2 of the H5. Carefully align pins to match.



2. Connect the other end of the XLR cable to the end of the shotgun microphone



3. Boom microphone can be attached to a boom pole or to a mic stand depending on the needs of your project.



4. Channel – Activate the channel that matches the mic input you wish to use.
 - Press the 1 or 2 channel button depending on your XLR inputs.



5. Adjust levels – Turn the corresponding levels dial to set the input levels (a.k.a. volume), from 1 to 10.
 - Sounds should peak at about the -6dB mark and not go higher so as to not clip.



6. Record and Transfer Files as usual with the H5 Recorder.